BIMTOSHARE

SHARE · REVIT

Revit-sneltoetsen

De 190 sneltoetsen waarmee wij dagelijks werken in Revit 2024, ingedeeld per onderwerp. Typ de letters gewoon achter elkaar in het tekenvenster, zonder Enter. Staan er meerdere toetsen bij een commando, dan werken ze allemaal.

Esc (2×)
Stopt het huidige commando en heft de selectie op.

Enter
Herhaalt het laatste commando. RC doet hetzelfde.

Zelf aanpassen
Typ KS. Met Import en Export deelt u één set met het hele team.

Selecteren

LK	Select links
MD	Modify
SA	Select All Instances: In Entire Project
Shift+D	IDs of Selection
Shift+I	Select by ID
SVV	Select All Instances: Visible in View

Modelleren

Bouwkunde, constructie en basiselementen.

//	Divide Surface
BM	Structural Framing: Beam
BR	Structural Framing: Brace
BS	Structural Beam System
CL	Column
CM	Place a Component
DR	Door
FT	Structural Foundation: Wall
GR	Grid
LI	Model Line
LL	Level
RM	Room
RN	Reinforcement Numbers
RP	Reference Plane
SB	Floor: Structural
WA	Wall
WN	Window

Bewerken

ACV	Paste: Aligned to Current View
AL	Align
AR	Array
CO CC	Copy
CP	Cope
CS	Create Similar
DE	Delete
DM	Mirror - Draw Axis
MA	Match Type Properties
MM	Mirror - Pick Axis
MV	Move
OF	Offset
PN	Pin
PT	Paint
RC	Cope: Remove Coping
RC	Repeat Last Command
RE	Scale
RO	Rotate
SF	Split Face
SL	Split Element
TR	Trim/Extend to Corner
UP	Unpin

Annoteren

DI	Aligned Dimension
DL	Detail Line
EL	Spot Elevation
EW	Edit Witness Lines
FR	Find/Replace
MCT	Multi-Category Tag
RT	Tag Room
RVC	Revision Cloud
TAN	Tag Room: Tag All Not Tagged

TG	Tag by Category
TX	Text

Elektrotechniek

CN	Conduit
CT	Cable Tray
EC	Check Circuits
EDC	Edit Circuit
EE	Electrical Equipment
ES	MEP Settings: Electrical Settings
EW WIA	Arc Wire
LF	Lighting Fixture
NF	Conduit Fitting
PS	Panel Schedules
RFC	Remove from Circuit
TF	Cable Tray Fitting
WC	Chamfered Wire
WL WIC	Convert to Wire: Chamfered Wire

Werktuigbouw en sanitair

AT	Air Terminal
CV	Convert to Flex Duct
DA	Duct Accessory
DC	Check Duct Systems
DF	Duct Fitting
DT	Duct
EP	Edit Part
FD	Flex Duct
FP	Flex Pipe
FS	MEP Settings: Fabrication Settings
HT	Show Help Tooltip
ME	Mechanical Equipment
MR	Multi-Point Routing
MS	MEP Settings: Mechanical Settings
PA	Pipe Accessory
PB	MEP Fabrication Parts
PC	Check Pipe Systems
PF	Pipe Fitting
PI	Pipe
PX	Plumbing Fixture
SK	Sprinkler

Weergave en zichtbaarheid

CX	Toggle Reveal Constraints Mode
EH	Hide in View: Hide Elements
EOD OGE	Override Graphics in View: Override by Element
EOG	Graphic Override by Element in View: toggle ghost surface
EOH	Graphic Override by Element in View: toggle halftone
EOT	Graphic Override by Element in View: toggle transparency
EU	Unhide Element
GD	Graphic Display Options
HC	Hide Category
HH	Hide Element
HI	Isolate Element
HL	Hidden Line
HR	Reset Temporary Hide/Isolate
IC	Isolate Category
LW	Linework
MVT	View Templates: Manage View Templates
RH	Toggle Reveal Hidden Elements Mode
SD	Shaded with Edges
TL	Thin Lines
VG VV	Visibility/Graphics
VH	Hide in View: Hide Category
VOG	Graphic Override by Category in View: toggle ghost surface
VOH	Graphic Override by Category in View: toggle halftone
VOT	Graphic Override by Category in View: toggle transparency
VR	View Range
VU	Unhide Category
WF	Wireframe

Views en presentatie

PP Ctrl+1 VP	Properties
RD	Cloud Rendering: Render in Cloud
RG	Cloud Rendering: Render Gallery
RR	Render
SCB	Scope Box
STN	Section
SWP	Show Work Plane

Navigeren en zoomen

32	2D Mode (3D Mouse)
3F	Fly Mode (3D Mouse)
3O	Object Mode (3D Mouse)
3W	Walk Mode (3D Mouse)
CIV	Close Inactive Views
Ctrl+`	Activate the first contextual tab
R3	Define a new center of rotation

TW	Tab Views
WT	Tile Views
ZA	Zoom All to Fit
ZE ZF ZX	Zoom to Fit
ZO ZV	Zoom Out (2x)
ZP ZC	Previous Pan/Zoom
ZR ZZ	Zoom in Region
ZS	Zoom Sheet Size

Snaps

Typ tijdens een commando om één keer een specifieke snap af te dwingen.

PC	Snap to Point Clouds
SC	Centers
SE	Endpoints
SI	Intersections
SM	Midpoints
SN	Nearest
SO	Snap Off
SP	Perpendicular
SQ	Quadrants
SR	Snap to Remote Objects
SS	Turn Override Off
ST	Tangents
SW	Work Plane Grid
SX	Points
SZ	Close

Groepen

AD	Attach Detail Group
AP	Add to Group
CG	Cancel
EG	Edit Group
EX	Exclude
FG	Finish
GP	Model Group: Create Group
LG	Link
MP	Move to Project
RA	Restore All Excluded
RB	Restore Excluded Member
RG	Remove from Group
UG	Ungroup

Samenwerken en projectinstellingen

BS	MEP Settings: Building/Space Type Settings
ER	Editing Requests
F11	Background Processes
F9	System Browser
GL	Global Parameters
KS	Keyboard Shortcuts
ML	Manage Links
MW	Worksets
RL RW	Reload Latest
SH	Shared Parameters
SU	Additional Settings: Sun Settings
UN	Project Units

Teksteditor

Werkt tijdens het bewerken van tekst.

Ctrl+=	Subscript
Ctrl+B	Bold
Ctrl+I	Italic
Ctrl+Q	Close Text Editor
Ctrl+Shift+=	Superscript
Ctrl+Shift+A	All Caps
Ctrl+U	Underline

Add-ins

Alleen beschikbaar als de betreffende add-in is geïnstalleerd (COINS, Cadac, DiRoots).

BX	AutoSection Box
Shift+P	ProSheets
VBC	Connector oplossingen: Verbind connectoren

Sommige toetsen werken alleen in een bepaald tabblad of tijdens een commando. Toetsen kunnen per Revit-versie of sjabloon verschillen.